

Shopping list supplement for various radio triggers

These are all available at Amazon UK, you will need to find the equivalent product for your own country. I don't continually update these products, so watch out for newer models

Please note that this is by no means an exhaustive list of triggers, there's a lot more and new ones are coming on to the market quite regularly.

Manual triggers (No LCD panel)

These triggers require you to physically walk over to the flash to change the flash power

[Yongnuo RF-603 III](#) - N3 for Nikon, C3 for Canon

[Pixel Soldiers](#) - Also available for Sony cameras

[Phottix Ares II](#)

[Neewer CT-16](#) - Cheapest option I've found

Manual triggers (With LCD panel)

These triggers allow you to change the flash power from the camera position

[Yongnuo YN 560-TX II](#) - Use with YN-560 III and IV speedlights

[Godox X1-T](#) – Use with Godox TT600

TTL and HSS triggers These are more expensive (useful though for outdoor photography)

[Yongnuo YN-622 TX](#) Trigger and receiver

[Godox XPro](#) – Trigger and Receiver

With all of these systems it is very important that you purchase the correct ones for your camera. Models are often denoted with an 'N' for 'Nikon', 'C' for Canon, 'S' for Sony etc... Buy the wrong type, and the flash will either not fire, or fire incoisitently.